






Assembly Instructions
 + Four Person + Assembly Recommended

Insert upper pole into lower pole




Parts List

 Yellow Pole x164	 Blue Pole x45	 Black Pole x45	 3-Way Corner x8	 4-Way Join x40	 Base x1	 Roof x2	 End Panel x2
 Equipment Hanger Ends x128	 Support Pole Rubber Foot x21	 Support Pole Rubber Top x21	 Straight Pole Connectors x42		 Left Side Panel x2	 Right Side Panel x2	 Centre Securing Ring x21

Check all parts and layout in groups before assembly


Step 1

Lay out base.
TIP: Ensure 360° Access.




Step 2

Assemble floor poles, 3-way corners and 4-way joins as shown.




Step 3

Assemble vertical poles x45




Step 4

Fit 3 of the vertical poles
Fit 3-way corner
Fit 4-way joins




Step 5

Fit support pole top and foot to x21 vertical poles




Link straight pole connectors and fit centre securing ring as shown. Refer to step 6 for location.




Step 6

Fit roof poles
Fit support pole
Fit straight pole connectors with centre securing ring




Step 7

Repeat as shown.




Step 8

Repeat as shown.



Step 9


Zip roof panels together as shown.



Step 10

Fit Roof


TIP: Start at one end and pull along from inside tent.



Step 11


Fit end panel 1 as shown.

TIP: Zip panel to roof first ①



Step 12


Repeat for end panel 2.



Step 13

Fit left side panel as shown.

TIP: Zip panel to roof first ①




Step 14

Fit right side panel as shown.

TIP: Zip panel to roof first ①

Repeat for other side



Step 15

Fit equipment hangers ends and place as required.

Upper Equipment Hanger
Lower Equipment Hanger

